


CRS09 CONNECTION TO CD-0026

You can check the rate output of CRS09 with CD-0026. Please see how to connect as follows.

■■ WIREING ■■



* CD-0026 doesn't show REF output of CRS09. Because no input of REF connection in CD-0026

■■ Connector ■■

【Connector for CRS09】

JAE P/N: IL-S-8P-S2L2-EF

WEB site: <http://www.iae.co.jp/e-top/index.html>

PIN No	Name
1	0V
2	+5V
3	Rate
4	REF
5	TMP
6	D.N.C
7	FRQ
8	N.C

【Connector for CD-0026】

JST P/N : XHP-3

WEB site: <http://www.jst-mfg.com/>

PIN No	Name
1	+5V
2	0V
3	Rate